Tailscale set-up

Tailscale on SMHUB (Quick Setup Guide)

Applies to all SMHUB models: Professional, Essential, Nano Mg24

Tested with:

- SMHUB-OS **v0.3.10**
- smhub-services **v0.2.7**
- smhub-web **v0.2.23**
- Tailscale app **v1.78.1-2**

---

1. Install Tailscale

- Open **Apps**
- Install the **Tailscale** app

---

2. Start Tailscale (Optional: Enable Autostart)

- Go to **Apps → Tailscale**
- Click **Run**
- *(Optional)* Enable **Start on boot** if you want Tailscale to start automatically after reboot

---

3. Authenticate Device

In **Console**, run: `sudo /opt/bin/tailscale up`

The system will print a login URL (for example): `https://login.tailscale.com/a/xxxxxx`

Open the link in your browser and authorize the device.

---

4. Connect Another Device

- Install Tailscale on your PC
- Log in with the **same account**
- Authorize the device

Once both devices are in the same tailnet, they can communicate securely.

Notes

- Authentication is **interactive** (browser required)
- After authorization, the terminal is no longer needed
- Tailscale reconnects automatically on reboot
- No port forwarding or firewall changes required

Revision #3
Created 2026-01-18 23:23:37 UTC by Support3
Updated 2026-01-18 23:30:46 UTC by Support3