
Buttons and LEDs functions



USB/LAN mode button switches the device from LAN to USB mode and vice versa.
This button is also used to force the device into USB firmware update mode, you need to hold it down and connect the device to USB while keeping it pressed.

Revision #1
Created 2026-07-27 12:48:17 UTC by Taras
Updated 2026-07-27 12:51:38 UTC by Taras