

SLWF-09

- [Introduction](#)
- [Hardware Overview](#)
- [Wiring and Installation](#)
- [Firmware Setup](#)
- [GPIO Allocation](#)
- [Troubleshooting](#)
- [Technical Specifications](#)
- [Frequently Asked Questions \(FAQ\)](#)
- [Note about device disassembling](#)

Introduction

Thank you for choosing the **SMLIGHT SLWF-09**, our most **flexible, modular, and feature-rich LED controller** to date.

Designed for enthusiasts, makers, and professionals, the SLWF-09 combines **ESP32 processing power** with the user-friendly **WLED firmware** to deliver stunning lighting effects for addressable LED strips.

Whether you need a **simple Wi-Fi setup** or a **professional wired installation with PoE**, the SLWF-09 adapts to your needs with **plug-and-play add-on modules**.

Key Features

- **ESP32-based** with 16 MB flash – powerful, reliable, and customizable.
- **Pre-flashed with WLED** – start controlling your LEDs immediately.
- **Modular add-on support:**
 - **Ethernet Module** – stable wired network connectivity.
 - **PoE Module** – single-cable power and data.
 - **Microphone Module** – unlock sound-reactive effects in WLED.
- Compatible with popular LED types: WS2812B, SK6812, APA102, and more (5V–12V).
- Supports **two LED channels by default**, expandable up to six via GPIO.
- Integrates seamlessly with **Home Assistant**, Node-RED, and other smart home platforms.

What's in the Box

- **SLWF-09 main controller board**
- Quick-start guide
- (Optional) Ethernet, PoE, or Microphone add-on modules if purchased together

About This Manual

This manual will guide you through:

1. **Hardware overview** – understanding your SLWF-09 and add-ons
2. **Wiring and installation** – safe connection of LEDs and power

3. **Firmware setup** – configuring WLED and integrations
4. **GPIO allocation** – reference table for advanced users
5. **Troubleshooting** – solutions to common issues

Important Notes

- Always disconnect power before attaching or removing add-on modules.
- Use a compatible power source matching your LED voltage (5V, 12V).
- If using the PoE module, ensure your network switch or injector supports IEEE 802.3af and you use 5V LED strip

Hardware Overview

The **SMLIGHT SLWF-09** is designed as a **modular, ESP32-based LED controller** with optional add-on boards for Ethernet, Power over Ethernet (PoE), and digital microphone functionality. This section describes the main components and interfaces of the SLWF-09 and its supported add-ons.

2.1 Main Board Features

- **ESP32-D0WD-V3** microcontroller with 16 MB flash memory
- **Pre-installed WLED firmware** for plug-and-play operation
- **Two LED control channels** by default (expandable to six via GPIO)
- **USB-C port** with UART auto-flash for firmware updates
- **Power input options:**
 - USB-C (supports PD negotiation - can drive either 5V or 12V LED strips)
 - VIN screw terminal (5-12V)
 - DC plug in (5-12V)
 - Wire terminal (5-12V)
 - PoE module (optional, **5V 800mA** output)
- **Two on-board buttons** for mode selection and reset
- **Expansion headers** for add-on modules (Ethernet, PoE, Microphone, future expansions)
- **Level-shifted LED outputs** for wide LED voltage compatibility (level shifting 5V)
- **DIY Terminal** - for external buttons sensors or relays.

2.2 Add-on Modules

2.2.1 Ethernet Module (Optional)

- Based on **LAN8720** Ethernet PHY
- Standard **RJ45 connector** with integrated magnetics and status LEDs
- 10/100 Mbps full-duplex operation
- Connects directly to the SLWF-09 via dedicated header
- Can be used standalone or with the PoE module

Benefits:

- Reliable, low-latency connection for installations where Wi-Fi is unstable or not preferred
- Full Home Assistant and WLED Ethernet support

2.2.2 PoE Module (Optional)

- IEEE 802.3af compliant (PoE Class 0)
- Integrated DC/DC converter provides regulated 5V (up to 800mA) power to the SLWF-09
- Connects between Ethernet add-on and network cable
- Eliminates the need for a separate power adapter

Benefits:

- Single-cable solution for both data and power
- Ideal for ceiling, wall, or inaccessible installations

2.2.3 Microphone Module (Optional)

- **ICS-43432** digital MEMS microphone
- Connects via dedicated header to ESP32 I²S pins
- Used by WLED to enable **sound-reactive LED effects**
- No additional power supply required (powered from main board)

Benefits:

- Real-time music synchronization without external sound sensors
- High-quality digital audio sampling

2.3 Physical Dimensions

- **Main Board:** approx. 57 × 30 × 23 mm
- **Ethernet Module:** approx. 60 × 18 × 15 mm
- **PoE Module:** approx. 31.5 × 28.7 × 16 mm
- **Microphone Module:** approx. 15 × 12 mm

2.4 Connectivity Summary

Interface	Description
USB-C	Power input (5V or 12V - based on switch selector) and UART programming
VIN	Screw terminal power input (5-12V)
LED OUT 1/2	Two independent addressable LED channels
Add-on Ports	Headers for Ethernet, PoE, and Microphone modules
Buttons	Boot/flash and reset/mode selection

Wiring and Installation

This section explains how to connect the SLWF-09 controller, add-on modules, and LED strips safely and correctly.

Follow all instructions carefully to ensure reliable operation and to avoid damage to the controller or connected equipment.

3.1 Safety Precautions

- **Disconnect power** before attaching or removing any cables or add-on modules.
- Verify that your **LED strip voltage matches the power supply voltage** (5V, 12V).
- **Never connect different voltage levels** (e.g., 12 V LED strip with 5 V power supply).
- When using **PoE**, ensure your network switch or injector supports **IEEE 802.3af**. **Please limit the current for the LED strip to 800mA**
- Observe correct polarity when wiring power and LED connections.

3.2 Powering the SLWF-09

You can power the SLWF-09 in **three different ways**:

1. **USB-C port** - 5V or 12V
 - Ideal for testing, firmware updates, or low-power LED setups.
 - Supports USB PD for negotiation, can supply 5V or 12V.
2. **DC plug-in** - 5V to 12V DC
 - Connect a DC plug into DC plug-in connector.
 - DC "+" goes to LED strips through the onboard MOSFET (relay) switch or to VCC directly bypassing MOSFET (relay).
3. **Wire fast-connect terminal** - 5V to 12V DC
 - Connect a wire directly to the VIN (+) and GND (-) terminals.
 - VIN also powers the LED strips through the onboard MOSFET switch.
4. **PoE Module (optional)** - IEEE 802.3af
 - Provides **5V 800mA** from an Ethernet connection via a PoE-enabled switch or injector.
 - Can be used together with the Ethernet add-on for single-cable operation.



3.3 Connecting LED Strips

The SLWF-09 supports most addressable LED protocols, including **WS2812B**, **SK6812**, **APA102**, and others.

Steps:

1. Identify your LED strip's **Data** (and optional **Clock**) lines, **V+**, and **GND**.
2. Connect **LED OUT 1** or **LED OUT 2** on the SLWF-09 to the corresponding LED strip input:
 - **Data** → DATA pin
 - **Clock** → CLOCK pin (only for clocked LED types such as APA102)
 - **V+** → LED supply voltage (must match power source)
 - **GND** → Common ground between SLWF-09 and LED strip
3. If controlling long LED runs, use an **external power injection** every several tens of meters to avoid voltage drop.

3.4 Installing Add-on Modules



3.4.1 Ethernet Module

1. Align the module with the **Ethernet header** on the main board.
2. Insert firmly, ensuring the keyed connector matches the socket.
3. Connect your network cable to the **RJ45 port**.

3.4.2 PoE Module

1. Install the PoE module between the **Ethernet add-on** and network cable.
2. Connect the network cable from a **PoE switch/injector** to the module.
3. The module will automatically power the SLWF-09.

3.4.3 Microphone Module

1. Align the module with the **MIC header** on the main board.
2. Insert carefully; the keyed connector ensures correct orientation.
3. Enable sound-reactive mode in **WLED settings**.

3.5 First Power-On

1. Double-check all wiring connections.
2. Apply power via your chosen method.
3. Observe the status LEDs:
 - **Power LED** - solid on when powered
 - **Status LED** - WLED activity indicator
4. Connect to the SLWF-09 via Wi-Fi or Ethernet to complete setup.

3.6 Recommended Installation Tips

- Mount the SLWF-09 in a **ventilated place** to protect from dust and accidental contact.
- For permanent installations, **secure cables with strain relief**.
- Keep **data wires short** to reduce signal degradation.
- Use **twisted pair or shielded cable** for long data runs.

Firmware Setup

1. The SLWF-09 comes pre-flashed with the latest stable **WLED firmware**, allowing you to start controlling LEDs right out of the box. This chapter explains how to connect to WLED for the first time, configure network settings, and update or change the firmware when needed.
-

4.1 First Connection to WLED

1. **Power on** the SLWF-09 using your chosen method (USB-C, VIN, or PoE).
 2. The device will create a **Wi-Fi Access Point (AP)** named: `WLED-AP`
Default password: `wled1234`
 3. Connect your phone or computer to this Wi-Fi network.
 4. Open a web browser and go to: `http://4.3.2.1`
 5. In the **Wi-Fi Setup** section, enter your home network SSID and password.
 6. Save and allow the SLWF-09 to reboot.
After reboot, it will connect to your home network and get an IP address from your router.
-

4.2 Ethernet Connection (Optional)

If you have installed the **Ethernet add-on**:

- Connect the Ethernet cable to your router/switch.
 - The SLWF-09 will automatically obtain an IP address via DHCP.
 - You can access WLED using this IP address directly.
-

4.3 Updating the Firmware

The SLWF-09 supports **OTA (Over-The-Air)** updates as well as flashing via USB-C.

Method 1 – OTA Update

1. Open the WLED web interface.
2. Go to **Config** → **Security & Updates**.
3. Select **Manual OTA Update**.
4. Upload the new `.bin` firmware file.

Method 2 – Web-based Flasher

You can easily flash the SLWF-09 directly from your browser using our official online flasher:

“ ???? <https://smlight.tech/flasher/#SLWF-09>”

- Requires **Google Chrome** or **Microsoft Edge**.
- Connect the SLWF-09 to your computer via USB-C.
- Follow the on-screen instructions to install WLED, ESPHome, or other compatible firmware.

Method 3 – USB-C via esptool

- Use `esptool.py` or similar utilities for advanced flashing.
- Hold **BOOT** (GPIO0) during power-up to enter programming mode.

4.4 Switching Firmware (WLED ? ESPHome)

- You can replace WLED with **ESPHome** for integration with **Home Assistant**.
- When switching from WLED to ESPHome, use the **Web-based Flasher** or **esptool** method.

4.5 Restoring Factory Defaults

- To reset network settings:
 1. Hold the **Boot/Flash** button for **5+ seconds** while powered.
 2. Release when the status LED blinks rapidly.
- The device will reboot into AP mode.

GPIO Allocation


The table below lists all ESP32 GPIOs used by the SLWF-09, their assigned functions, and the type of interface or peripheral they control.

Pins marked with “*” are only used when the corresponding **add-on module** (Ethernet or Microphone) is installed.

The PoE add-on does not consume any GPIO pins.

Type	Function	GPIO
Boot/Prog	Not exposed	GPIO0
LED	On board LED	GPIO2
LED	LED data output 1 (DATA)	GPIO4
LED	LED data output 2 (for clocked LEDs)	GPIO17
I ² C	I ² C SCL (expansion) (10k pull up)	GPIO5
I ² C / Mic	I ² C SDA / Mic SCK* (10k pull up)	GPIO14
Mic	Mic WS*	GPIO15
Mic	Mic SD*	GPIO32
Ethernet	PHY RXER*	GPIO13
Ethernet	PHY Clock Enable / OSCEN*	GPIO16
Ethernet	MDIO*	GPIO18
Ethernet	TXD0*	GPIO19
Ethernet	TXEN*	GPIO21
Ethernet	TXD1*	GPIO22
Ethernet	MDC*	GPIO23
Ethernet	RXD0*	GPIO25

Type	Function	GPIO
Ethernet	RXD1*	GPIO26
Ethernet	CRS_DV*	GPIO27
Relay	LED power line control	GPIO33
Button	Button 1	GPIO34
DIY1	DIY input/output	GPIO36
Ethernet	Ethernet detect*	GPIO37
DIY2	DIY input/output	GPIO38
Button	Button 2	GPIO39
Reserved	Not connected (NC)	GPIO35



Troubleshooting

This section lists common issues you may encounter while using the SLWF-09, along with their possible causes and solutions.

6.1 Power Issues

Problem	Possible Cause	Solution
No power LED when connected	<ul style="list-style-type: none">- Incorrect power supply voltage- Loose or reversed wiring- Faulty power adapter- Incorrect WLED relay settings	<ul style="list-style-type: none">- Verify voltage matches LED strip (5V, 12V)- Check all power connections- Try a different power source- "Relay GPIO" setting should be GPIO33
Device powers on but LEDs do not light	<ul style="list-style-type: none">- Incorrect LED wiring- Wrong LED type in WLED- Data wire not connected- LED relay is not configured	<ul style="list-style-type: none">- Verify data and ground connections- Match LED type in WLED settings- Check continuity of data wire- Configure LED relay in WLED to GPIO33

6.2 Network Connection Problems

Problem	Possible Cause	Solution
Cannot find WLED Wi-Fi AP on first boot	<ul style="list-style-type: none">- Device already connected to a previous network	<ul style="list-style-type: none">- Reset Wi-Fi settings by holding BOOT button for 5+ seconds until LED blinks rapidly
Cannot connect to home Wi-Fi	<ul style="list-style-type: none">- Wrong SSID/password- Unsupported 5 GHz Wi-Fi	<ul style="list-style-type: none">- Double-check credentials- Ensure router has 2.4 GHz enabled
Ethernet not working (with add-on)	<ul style="list-style-type: none">- Module not fully inserted- No DHCP from router	<ul style="list-style-type: none">- Reseat Ethernet module- Try a different cable/port- Check if IP is assigned in router

6.3 LED Output Issues

Problem	Possible Cause	Solution
LEDs flicker or show wrong colors	<ul style="list-style-type: none"> - Voltage drop on long runs - Poor grounding - Incorrect LED voltage 	<ul style="list-style-type: none"> - Use power injection - Ensure common ground - Match LED strip voltage to power supply
Only first few LEDs light up	<ul style="list-style-type: none"> - Power not sufficient - WLED LED count too low 	<ul style="list-style-type: none"> - Increase power supply capacity - Set correct LED count in WLED

6.4 Add-on Module Problems

Problem	Possible Cause	Solution
PoE not powering device	<ul style="list-style-type: none"> - Non-PoE switch/injector - Incorrect PoE standard 	<ul style="list-style-type: none"> - Use IEEE 802.3af compliant PoE source
Microphone not detected	<ul style="list-style-type: none"> - Module not inserted fully - Sound reactive mode not enabled in WLED 	<ul style="list-style-type: none"> - Reinsert module correctly - Enable "Sound Reactive" in WLED settings

6.5 Firmware & Reset

Problem	Possible Cause	Solution
WLED interface not loading	<ul style="list-style-type: none"> - Firmware corrupted - IP conflict 	<ul style="list-style-type: none"> - Reflash firmware via Web Flasher
Device unresponsive after update	<ul style="list-style-type: none"> - Incorrect firmware build 	<ul style="list-style-type: none"> - Flash with correct SLWF-09 firmware using USB-C and web flasher

6.6 Support

If problems persist:

1. Visit the documentation at <https://smlight.tech/support/manuals/public/books/slwf-09>
2. Use the [Web Flasher](#) to reinstall firmware.
3. Contact **SMLIGHT Support** with your purchase details and a description of the issue.

Technical Specifications

The following table lists the key hardware and electrical specifications of the **SMLIGHT SLWF-09** LED controller and its supported add-on modules.

7.1 Main Board

Parameter	Specification
MCU	ESP32-D0WD-V3, dual-core 240 MHz
Flash Memory	16 MB
Default Firmware	WLED (latest stable release)
Power Input Options	USB-C (5V or 12V), DC plug-in terminal (5V-12V DC), VIN fast-clips terminal (5V-12V DC), PoE via add-on (5V output)
LED Output Channels	2 channels (expandable up to 4 via DIY GPIO)
Supported LED Types	WS2812B, SK6812, APA102, and other 3-wire or 4-wire addressable LEDs
Max LED Voltage	12V
Max LED Current	With an external PSU (current passes through the controller terminals) - up to 20A . With an external PSU directly connected to the LED strip - unlimited . Using USB-C - up to 5A . Using DC5.5 - up to 3A . Using POE Addon - up to 800mA .
Data Level Shifting	On-board 3.3V → 5V
Connectivity	Wi-Fi 2.4 GHz (IEEE 802.11 b/g/n), Ethernet via add-on
USB Interface	USB-C with UART auto-programming
Buttons	2 buttons, fully configurable
Operating Temperature	-10 °C to +60 °C
Dimensions	57 × 30 × 23 mm

7.2 Ethernet Add-on (Optional)

Parameter	Specification
Ethernet PHY	LAN8720
Speed	10/100 Mbps full-duplex
Connector	RJ45 with integrated magnetics and status LEDs
Power Requirement	Powered by main board
Dimensions	60 × 18 × 15 mm

7.3 PoE Add-on (Optional)

Parameter	Specification
PoE Standard	IEEE 802.3af Class 0
Input Voltage	37-48 V DC via Ethernet cable
Output Voltage	5 V DC regulated
Max Output Power	Recommended long-term power: 4W Maximum peak power: up to 12.95 W
Dimensions	31.5 × 28.7 × 16 mm

7.4 Microphone Add-on (Optional)

Parameter	Specification
Microphone Type	ICS-43432 digital MEMS
Interface	I ² S
Frequency Response	60 Hz - 15 kHz
Power Requirement	3.3 V (supplied from main board)
Dimensions	15 × 12 mm

Frequently Asked Questions (FAQ)

The Ethernet connection is not working, what should I check?

A:

- Ensure the Ethernet module is fully seated in its connector.
 - Verify the cable and router/switch port are working.
 - Check that your router's DHCP is enabled.
-

Does the PoE module support passive PoE?

A: No, only **IEEE 802.3af** active PoE is supported.

How do I enable sound-reactive effects?

A: Install the **Microphone add-on**, then enable "Sound Reactive" mode in WLED settings.

Can I use SLWF-09 with ESPHome?

A: Yes, you can flash ESPHome firmware using the web flasher or USB-C. Make sure to configure GPIO mapping according to the "GPIO Allocation" chapter.

Can I run the SLWF-09 in both Wi-Fi and Ethernet modes at the same time?

A: Yes, the ESP32 can maintain Wi-Fi and Ethernet simultaneously. However, WLED will usually prioritize Ethernet for control traffic.

How do I reset the device to factory defaults?

A: Reflash device using this tool <https://smlight.tech/flasher/#SLWF-09>

Can I power the controller by POE and use other power input for the LEDs?

A: You can **only use one** power source at a time: either PoE or external DC power. **It is STRICTLY FORBIDDEN to power the device simultaneously from different power sources.**

Is it normal that powering the unit to I don't see any status led visible?

A: Yes it is normal, by default the indicators are not on but you can press one of the buttons and you will see the LED indication.

Note about device disassembling

Use a **thin** and **sharp** tool for opening the device cover. Insert it into the center of the terminal connector as shown in the photo below:



Once the tool is inserted, start pulling the PCB down from the Type-C connector side:

