

7. User Interface

The SMHUB web interface is the primary way to configure and manage the system. It provides access to dashboards, built-in applications, and detailed system settings.

7.1 Dashboard

The **Dashboard** is the starting page of the interface and shows an overview of the hub:

- **System Information**
 - Device model, firmware version, uptime.
 - CPU load, memory usage, and storage status.
 - **Network Status**
 - Ethernet/Wi-Fi interfaces with IP addresses.
 - VPN (WireGuard) status.
 - **Radio Status**
 - Zigbee, Thread, Z-Wave (if installed), Bluetooth.
 - Service LED indicators and Ambilight effects.
 - **Service Overview**
 - Running state of **Zigbee2MQTT**, **Matterbridge**, **Node-RED**, **Mosquitto MQTT broker**.
 - Quick buttons to start/stop services.
-

7.2 Zigbee2MQTT

- Direct integration with the **Zigbee2MQTT frontend**.
 - Allows pairing, removing, and managing Zigbee devices.
 - Displays a network map, device states, and logs.
 - Zigbee devices are automatically published to the local **Mosquitto MQTT broker**.
-

7.3 Matterbridge

- Provides direct access to the **Matterbridge frontend**.
- Manages bridging between Zigbee/Thread devices and Matter ecosystems (Google Home, Apple Home, Alexa, SmartThings).

- Allows configuration of bridge modes and Matter controllers.
-

7.4 Node-RED

- Opens the **Node-RED frontend**, a visual automation editor.
 - Users can create and deploy flows combining Zigbee2MQTT, Matterbridge, MQTT, HTTP APIs, or custom integrations.
 - Pre-installed flows include templates for MQTT and device automation.
-

7.5 Apps

The **Apps** section acts as a package manager for SMHUB applications.

- **App Management**
 - Install, uninstall, or update applications.
 - Configure settings per application.
 - Start/stop applications with one click.
 - **Preinstalled Apps**
 - Zigbee2MQTT
 - Matterbridge
 - Node-RED
 - Mosquitto MQTT broker
 - **Additional Apps**
 - Future apps (e.g., Z-Wave JS, custom services) can be added here.
 - Apps can be distributed as packages and installed via this page.
-

7.6 Settings

The **Settings** section contains all configuration options for SMHUB. It is divided into modules, each with tabs for **configuration, telemetry, and debug** where available.

System

- Hostname, time zone, system info.
- User management (accounts, passwords).
- Updates (firmware & app updates).
- Backup & restore.

- Factory reset.

Network

- Ethernet (DHCP/static).
- Wi-Fi (2.4/5 GHz, AP/Client mode).
- VPN (WireGuard).
- DDNS configuration (DuckDNS, others).
- USB-over-network.

Radios

- Zigbee: coordinator settings, pairing mode, diagnostics.
- Thread: OTBR management, Matterbridge integration.
- Z-Wave (if module installed): inclusion/exclusion, network management.
- Bluetooth: enable/disable, scanning, BLE integrations.
- 4G/LTE (in development): SIM/APN settings, LTE telemetry, GPS data.

Audio & Buzzer

- Volume control (3.5 mm output).
- Enable/disable system notification sounds.
- Buzzer toggle and test alerts.

LEDs

- Service LED control.
- Ambilight modes (status, animations, user-defined patterns).

IR

- IR transmitter: configure/send commands.
- IR receiver: learn remote commands and store them.

Storage

- SD card and eMMC info.
- Format, mount/unmount.
- Telemetry: usage stats.

Security

- User authentication settings.
 - SSH toggle.
 - VPN certificates and DDNS keys.
 - Firewall and remote access rules.
-

Revision #1

Created 8 September 2025 16:37:12 by Support3

Updated 8 September 2025 16:53:48 by Support3